

Recommended Xerox Media for Phaser 6300N, 6300DN, 6350DP, 6350DT, and 6350DX (Europe)



Revision 6.0, Publish Date: December, 2007

Important Note:

All media are listed by product, Paper Type System Setting, Paper Type, weight (standard gsm), re-order number, size, and tray runability. The additional information column is for hints and tips on how to run certain media applications.

Media recommendations made in this publication are based on qualification tests* conducted using standard test images with moderate to heavy image area coverage. Test duration for each product/media type is based on the suggested machine monthly copy/print volume. Test machines are maintained within specifications defined by user documentation.

*Testing environment Temperature 20 degreesC±4, Relative Humidity 40% ±10%.








*Machine reliability specifications may be affected by increased usage of the Transparency, Card Stock, Label, and Special modes. In addition, variances in machine reliability may occur due to extended use of some media types. Your Xerox service representative can advise you on special application media types for long duration copy/print runs.

For specifications and a description of the various media types discussed in this publication, please refer to www.Xerox.com.

For additional recommended Phaser media, look under Supplies on: <http://www.office.xerox.com/> and select your Product Family.

© 2005 Xerox Corporation. All rights reserved.

Xerox®, The Document Company®, the stylized X®, and all Xerox product names and product names and product numbers mentioned in this publication are trademarks of Xerox Corporation. Other company trademarks are also acknowledged.

| | |
|---------------|---|
| Plain |  |
| Heavy Plain |  |
| Thin Card |  |
| Thick Card |  |
| Glossy Coated |  |
| Label |  |
| Transparency |  |

December, 2007
Phaser 6300N,
6300DN, 6350DP,
6350DT, and 6350DX

A=Auto Duplex
M=Manual Duplex
S=Simplex Only



| Paper | Paper Type | Weight | Re-Order # | Cross Reference # | Type | Size | Trays | | | | | Additional Information |
|--------------------------|-------------|---------|------------|-------------------|------|------|-------|---|---|---|---|--|
| | | | | | | | 1/MPT | 2 | 3 | 4 | 5 | |
| Xerox Colotech+ | Plain | 90 gsm | 3R97988 | | | A4 | A | A | A | A | A | Refer to the "Paper Tips" embedded page for additional printer-specific information, e.g., High Capacity tray usage. |
| | Heavy Plain | 100 gsm | 3R97993 | | | A4 | A | A | A | A | A | Paper Type <i>Plain</i> should be selected on the user interface for Trays/MPT. For higher print gloss, use the <i>Heavy Plain</i> setting. |
| | Heavy Plain | 120 gsm | 3R97958 | | | A4 | A | A | A | A | A | Paper Type <i>Heavy Plain</i> should be selected on the user interface for Trays/MPT. |
| | Thin Card | 160 gsm | 3R97963 | | | A4 | A | A | A | A | A | Paper Type <i>Thin Card</i> should be selected on the user interface for Trays/MPT. |
| | Thick Card | 200 gsm | 3R97967 | | | A4 | M | | | | | Paper Type <i>Thick Card</i> should be selected on the user interface for Trays/MPT. Environmental condition may require that this product be fed one sheet at a time. |
| Xerox Colour Impressions | Plain | 90 gsm | 3R97663 | | | A4 | A | A | A | A | A | Paper Type <i>Plain</i> should be selected on the user interface for Trays/MPT. For higher print gloss, use the <i>Heavy Plain</i> setting. |
| Xerox Business | Plain | 80 gsm | 3R91820 | | | A4 | A | A | A | A | A | Paper Type <i>Plain</i> should be selected on the user interface for Trays/MPT. |
| Xerox Premier | Plain | 80 gsm | 3R91720 | | | A4 | A | A | A | A | A | Paper Type <i>Plain</i> should be selected on the user interface for Trays/MPT. |
| | Thin Card | 160 gsm | 3R93009 | | | A4 | A | A | A | A | A | Paper Type <i>Thin Card</i> should be selected on the user interface for Trays/MPT. |
| Xerox Performer | Plain | 80 gsm | 3R90649 | | | A4 | A | A | A | A | A | Paper Type <i>Plain</i> should be selected on the user interface for Trays/MPT. |
| Xerox Recycled | Plain | 80 gsm | 3R91165 | | | A4 | A | A | A | A | A | Paper Type <i>Plain</i> should be selected on the user interface for Trays/MPT. Performance may vary at extremes in humidity. |



| | |
|---------------|--|
| Plain | |
| Heavy Plain | |
| Thin Card | |
| Glossy Coated | |
| Transparency | |
| Thick Card | |
| Label | |

**December, 2007
Phaser 6300N,
6300DN, 6350DP,
6350DT, and 6350DX**

A=Auto Duplex
M=Manual Duplex
S=Simplex Only

| Paper | Paper Type | Weight | Re-Order # | Cross Reference # | Type | Size | Trays | | | | | Additional Information |
|--|---------------|---------|------------|-------------------|------|----------|-------|---|---|---|---|---|
| | | | | | | | 1/MPT | 2 | 3 | 4 | 5 | |
| Xerox Digital Colour Colotech+ Gloss | Glossy Coated | 140gsm | 3R97577 | | | A4 | A | A | A | A | A | Refer to the "Paper Tips" embedded page for additional printer-specific information, e.g., High Capacity tray usage. Paper Type <i>Glossy Coated</i> should be selected on the user interface. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage prints. Paper Type <i>Thick Card</i> should be selected on the user interface. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage prints. |
| | Thick Card | 210gsm | 3R97583 | | | A4 | M | | | | | |
| Xerox Trifold Brochures | Thin Card | 176 gsm | 3R97946 | 103R01019 | | A4 | M | | | | | Paper Type <i>Thick Card</i> should be selected on the user interface for Tray1/MPT. |
| Xerox Premium Business Cards | Thick Card | 195gsm | 3R97512 | | | A4 | M | | | | | Paper Type <i>Business Card</i> should be selected on the user interface for Tray1/MPT. |
| Xerox Colour Laser/ Copier Labels | Label | | 3R93872 | | | 1 up A4 | S | S | S | S | S | Paper Type <i>Labels</i> should be selected on the user interface for Trays/MPT. |
| | | | 3R93873 | | | 6 up A4 | S | S | S | S | S | |
| | | | 3R93874 | | | 8 up A4 | S | S | S | S | S | |
| | | | 3R93875 | | | 14 up A4 | S | S | S | S | S | |
| Xerox Phaser™ 25-Series Premium Transparencies | Transparency | | | 016-1948-00 | | A4 | S | S | S | S | S | Paper Type <i>Transparency</i> should be selected on the user interface for Trays/MPT. It is not recommended to output more than 20 transparencies at a time. |

WARRANTY DISCLAIMER

Xerox makes no guarantees or warranties, either express or implied, concerning the performance, use or replacement of non-Xerox branded media or throughput products. Customers should inquire directly of their paper distributor or manufacturer for any guarantees they may offer. When purchasing a particular media product for the first time, customers are advised to purchase small quantities to insure that their expectations are met.

The quality of Xerox supplies is consistent from ream to ream, carton to carton, and it is backed by a Xerox 100% guarantee. The quality of non-Xerox branded paper may vary from ream to ream or carton to carton, so for optimum performance on Xerox color equipment, use only the best--Xerox Supplies.

© 2005 Xerox Corporation. All rights reserved.

Xerox®, The Document Company®, the stylized X®, and all Xerox product names and product numbers mentioned in this publication are trademarks of Xerox Corporation. Other company trademarks are also acknowledged.